


planck[®] O1

Quick Start Guide

快速入门手册

快速入門手冊

v1.0 2020.7



Disclaimer and Warning

Congratulations on purchasing your new **evowera**[®]**planck**[®]O1 adaptive control sonic electric toothbrush (hereinafter referred to as 'product'). Read this entire document carefully to ensure proper configuration before use and it is recommended to keep this document for future reference. This product is a personal care device. By using this product, you hereby agree to this disclaimer and signify that you have read it fully. Please use this product in strict accordance with the document, user manual, related regulations, terms of use and be sure to pay attention to the Important.

Shenzhen EVOWERA Technology Co., Ltd assumes no liability for damage(s) or injuries incurred directly or indirectly from improper use of this product. Misuse includes, but is not limited to, using unapproved chargers, or modifying the product.

evowera and **planck** are trademarks of Shenzhen EVOWERA Technology Co., Ltd (abbreviated as "**evowera**"). Names of products, brands, etc., appearing in this document are trademarks or registered trademarks of their respective owner companies. This product and document are copyrighted by **evowera** with all rights reserved. No part of this product or document shall be reproduced in any form without the prior written consent or authorization of **evowera**.

This disclaimer is produced in various languages. In the event of divergence among different versions, the Chinese version shall prevail when the product in question is purchased in China, and English version shall prevail when the product in question is purchased in any other countries or regions.

Important

Danger


- Keep the power adapter away from water. DO NOT place the power adapter over or near any container with water. DO NOT drop the power adapter into water or any kind of liquid. After cleaning, make sure the power adapter is completely dry before connecting it to a power outlet.

Warning

- Always use officially approved power adapter to charge to avoid electric hazards.

- DO NOT use the power adapter outdoors or near heated surfaces.
- If any part of this product gets damaged in any form (e.g:brush head, handle, charging dock or power adapter), stop using it immediately.
- DO NOT let children use, clean or maintain this product without supervision.
- DO NOT let children play with this product.
- DO NOT clean the brush head, the handle, the charging dock or the power adapter in the dishwasher.
- Consult your dentist before using this product if you have had oral or gum surgery in the previous two months.
- Consult your dentist if excessive bleeding occurs after using this product or if bleeding continues to occur after one week of use or if you feel discomfort or pain when using planck O1.
- planck O1 complies with the safety standards for electromagnetic devices. If you have a pacemaker or other implanted device, contact your physician or the device manufacturer of the implanted device before use.
- If you have medical concerns, consult your doctor prior to use.
- This product is only designed for cleaning teeth, gums, and tongue. DO NOT use it for any other purpose. If you experience any discomfort or pain, stop using this product and contact your doctor.
- planck O1 is a personal care device, and is not intended to be used by dental clinics or institutions for multiple patients.
- Stop using a brush head with crushed or bent bristles or when planck O1 reminds you the brush head has exceeded its lifespan. DO NOT use other brush heads than the ones recommended by the manufacturer.

Overview




- ① Handle
- ② Metal Shaft
- ③ Function Button(Mode/Force)
- ④ On/Off Button
- ⑤ LCD Screen
- ⑥ Brush Head
- ⑦ Hygienic Brush Head Cap
- ⑧ Charging Dock
- ⑨ USB Connector
- ⑩ Power Adapter
- ⑪ USB Port
- ⑫ Power Connector
- ⑬ Quick Start Guide

Charging


Charge the toothbrush before first use. While charging, please note:

①



Gently place the toothbrush on the charging dock to avoid the toothbrush from being damaged.

②



Make sure to connect the charging dock to an AC power outlet of a voltage between 100 to 240V, frequency between 50-60Hz.

Downloading and Installing evowera App

Scan the QR code below or go to App store to download evowera App. Please follow the instruction to register an evowera account and log in.



QR Code

Activating

To ensure optimal usage experience and to enjoy better after-sales service, please follow the steps below to activate the toothbrush using evowera App before first use.


Wake up the toothbrush

- Press **function button once** or **press on/off button once** or **slightly shake** the toothbrush to wake it up.

Connection and Activation

- Launch evowera App and log in. Enter device connection page, and then place your toothbrush near your phone. Follow the prompts to complete activation.

Note: Make sure your mobile device is connecting to the internet during activation. Retry if activation fails. Contact **evowera** if activation fails for several times.



Button configuration



Device connection configuration

Basic Operations

Brushing Teeth

Press on/off button to switch on the toothbrush after it has been woken up.

Selecting Brushing Mode

After waking up your toothbrush, when the LCD screen is displaying home page and the toothbrush has not started working:

- ① Press **function button once** to enter mode setting page. Follow the prompts and **short press function button** to select the mode.
- ② **Press and hold function button** to confirm mode and exit to home page. **Press on/off button once** to start brushing teeth.


Adjusting Brushing Force

Note: You can only adjust the brushing force while using the toothbrush.

- Level by level: the brushing force will increase to a higher level every time you **press function button**.

Note that when the brushing force reaches the highest safe level, it will go down to the lowest if you press function button again.

- Skip through levels: **Press and hold function button**, and the brushing force will increase continuously **until you release function button**. Note that when the brushing force reaches the highest safe level, it will go down to the lowest and then increase again.



Checking Tooth-brushing Data

When the brush head is vibrating:

- ① Press on/off button once to stop the brush head vibration. The LCD screen will enter "Coverage" page.
- ② Press function button once to enter "Rating" page.
- ③ Press function button again to return to home page.

When the toothbrush is waking up, but not vibrating:


- ① **Press function button twice** to check record about your previous tooth brushing.
- ② **Press function button again** to return to home page.

Recording Your Periods

When the LCD screen is displaying home page and the brush head has not started vibrating yet:

- ① **Press and hold function button for 3 seconds** to enter "Female Period Tracker" page.
- ② Following the prompts, **press and hold function button** to record your period. The notice of "record with success" will appear on the LCD screen.
- ③ Check the LCD screen to see if you successfully record your period. If not, follow the instructions to retry.



*The LCD screen will return to home page if the toothbrush is idle for a while.





Using the Toothbrush

Follow the steps below to use the toothbrush:



- ① Attach the brush head
- ② Wet the bristles



- ③ Apply a small amount of toothpaste
- ④ Place the toothbrush bristles against the teeth at a slight angle (around 45 degrees)



- ⑤ Power on your planck O1
- ⑥ Gently move the brush head slowly across the teeth.






planck O1 can be safely used with:

- orthodontic appliances (it will accelerate bristle wear)
- restored tooth (dental filling, teeth crown, porcelain teeth)

Cleaning

- ① Remove the brush head, rinse the mental shaft area. Be sure to remove any remaining toothpaste.
- ② Use wet cloth to clean the handle.
- ③ After each use, rinse the brush head and bristle.
- ④ Remove brush head from handle, rinse the joint area at least once a week.
- ⑤ Use wet cloth to clean wireless charging dock and adapter. Be sure to remove any remaining toothpaste or other residues.



Storage

If you are not going to use the toothbrush for an extended period, unplug the charging dock from the wall socket. Clean the toothbrush thoroughly and store it in a cool and dry place away from direct sunlight.

Specifications

Product Name: planck O1 Adaptive Sonic Electric Toothbrush

Product Model: planck O1

IP Rating: IPX7

Rated Voltage: 7.4V

Rated Power: 4.0W

Operating Frequency: 2.402-2.480GHz

EIRP: $\leq 2\text{dBm}$

Battery Capacity: more than 1040mAh

Adapter Input: 100-240V ~ 50-60Hz, $\leq 350\text{mA}$

Manufacture: Shenzhen EVOWERA Technology Co.,Ltd

Warranty and Support

If you encounter any problem in using the toothbrush while having no time to go to local **evowera** authorized dealer for support, feel free to request mail-in repair service provided by **evowera**.

How to apply for mail-in repair service

Via **evowera** App:

- ① Launch **evowera** App and tap to select "Mail-in Repair Service". Fill in and submit the form.
- ② If you have already submitted your request for mail-in repair service, tap "Status" to check the repair progress.

Warranty Restrictions

The terms of the international warranty do not include the following:

- ① Brush Heads
- ② Damage caused by use of unauthorized replacement parts.
- ③ Damage caused by misuse, abuse, neglect, alterations or unauthorized repair.
- ④ Normal wear and tear, including but not limited to chips, scratches, abrasions, discoloration or fading.

Visit **evowera official website to see detailed information on warranty policies.**

This content is subject to change.

Download the latest version from
<http://www.evowera.com/plancko1>

免责声明和 safety 注意事项

感谢您购买 **evowera® planck® O1** 自适应声波电动牙刷。在使用本产品前，请仔细阅读本说明书并妥善保管以备日后参考。本产品属于私人用品，一旦使用，即被视为对本声明全部内容的认可和接受。请严格遵守手册、产品说明书和相关的法律法规、政策、准则安装和使用该产品。

在使用产品过程中，用户承诺对自己的行为及因此而产生的所有后果负责。因用户不当使用、安装、改装造成的任何损失，深圳市一唔未来科技有限公司将不承担任何法律责任。

evowera 和 **planck** 是深圳市一唔未来科技有限公司的商标。本文出现的产品名称、品牌等，均为其所属公司的商标或注册商标。本产品及手册为深圳市一唔未来科技有限公司版权所有。未经许可，不得以任何形式复印翻印。

关于不同语言版本的免责声明可能存在的语义差异，中国以中文版为准，其他国家或地区以英文版为准。

重要安全信息


危险

- 使电源适配器远离水源。请勿将它放置或存放在任何有水的容器的上方或附近。请勿将电源适配器侵入水或任何其他液体中。清洁后，确保电源适配器完全干燥，再将其连接至电源。

警告

- 应始终使用原装型号的电源适配器进行更换，以免发生危险。
- 切勿在户外或高温表面附近使用电源适配器。
- 如果本产品受到任何损坏（刷头、牙刷手柄、无线充电基座或电源适配器），请停止使用。
- 不要让儿童在无人监督的情况下对本产品进行使用、清洁和保养。
- 切勿让儿童玩弄本产品。
- 请勿在洗碗机中清洗牙刷头、牙刷手柄、无线充电基座和电源适配器。
- 如果您在两个月内接受过口腔或牙龈手术，请在使用本产品前先咨询您的牙医。
- 如果在使用本产品后牙龈大量出血或在使用一周后仍会出血，请咨询您的牙医。如果在使用 **planck O1** 时感觉不适或疼痛，也请咨询您的牙医。
- **planck O1** 符合电磁装置的安全标准。有关任何涉及心脏起搏器或其他植入装置的问题，请在使用之前咨询医生或相关植入装置的设备制造商。
- 如果您有医学问题，请在使用 **planck O1** 前咨询医生。
- 本产品设计仅用于清洁牙齿、牙龈和舌头。请勿将其用作任何其它用途。如果感觉任何不适或疼痛，请停止使用本产品并与医生联系。
- **planck O1** 为私人用品，不可供牙医诊所或机构对多位患者使用。
- 请停止使用变形、刷毛弯曲或 **planck O1** 屏幕提示超出使用寿命的牙刷头。请勿使用非制造商推荐的其他刷头。

整体部件图



背面


正面

- ① 牙刷手柄
- ② 刷头轴
- ③ 功能按键 (模式/力度)
- ④ 电源按键
- ⑤ 显示屏
- ⑥ 牙刷头
- ⑦ 牙刷头保护套
- ⑧ 无线充电基座
- ⑨ 充电底座 USB 接头
- ⑩ 电源适配器
- ⑪ 适配器 USB 接口
- ⑫ 适配器电源插头
- ⑬ 快速入门手册

充电


首次使用可能电量不足，需要充电，充电需要注意以下事项：

①



正确将牙刷放置在无线充电基座上，切勿硬塞防止牙刷手柄表面磨损。

②



在交流电 100-240V, 50-60Hz 电源插座上充电。

安装 evowera App

扫描下方二维码或在应用商店搜索并下载安装“evowera App”。安装完毕后，请按照 App 指引注册 evowera 账户并登录。



二维码

激活 planck O1

为保证产品功能的完整体验，享受正常便捷的售后服务，首次使用 planck O1 需连接手机并通过 evowera App 激活。请按照以下步骤完成激活操作：

唤醒牙刷

- 通过 **短按 1 次 功能按键 / 短按 1 次 电源按键 / 轻轻晃动牙刷** 三种方式可唤醒牙刷。


连接并激活

- 打开已经注册并完成登录的 App，进入设备连接界面。将牙刷放置于靠近手机的位置，按照 App 指引连接牙刷并完成激活。

注意：激活过程中请确保移动设备可正常接入互联网。若激活失败，请退出重试。多次激活失败，请联系 **evowera**。



按键示意图



连接设备示意图

按键功能基础操作

快速刷牙

短按 1 次 电源按键 开启或关闭刷头振动。

选择以及更换刷牙模式

当牙刷刷头处于静止状态且牙刷屏幕界面为主界面时：


- ① **短按 1 次 功能按键** 进入模式选择界面，根据牙刷屏幕显示内容，通过 **短按 功能按键** 进行模式选择。
- ② **长按 功能按键** 确定模式选择并返回主界面。或 **短按 1 次 电源按键** 确定模式选择并开启刷头振动。

调整刷牙力度

注意：牙刷力度调节只能在牙刷刷头振动的同时进行调节。

- 梯度式调节：**短按 1 次 功能按键** 升高一级刷牙力度（当到达最强安全力度时，继续 **短按 1 次 功能按键** 力度降至最弱）

- 无级变速式：**长按 功能按键** 并保持不放，刷牙力度持续增强。**放开 功能按键**，牙刷将保持放开瞬间的力度。（当到达最强安全力度时，力度重新由最弱向上递增）。



查看刷牙数据

刷头振动时：

- ① **短按 1 次 电源按键** 关闭刷头振动，牙刷屏幕出现“刷牙覆盖率”界面。
- ② 继续 **短按 1 次 功能按键** 牙刷屏幕进入“刷牙评分”界面。
- ③ 再次 **短按 1 次 功能按键** 返回主界面。

刷头静止时：


- ① 连续 **短按 2 次 功能按键** 查看上一次刷牙记录。
- ② 继续 **短按 1 次 功能按键** 返回主界面。

女性生理期记录

当牙刷刷头处于静止状态且牙刷屏幕界面为主界面时：

- ① **长按 3 秒 功能按键** 进入女性生理期记录界面。
- ② 根据屏幕界面信息提示，**长按 1 次 功能按键** 记录女性生理期，并可阅读到牙刷屏幕显示的记录成功信息。
- ③ 如果记录失败，请根据屏幕界面信息引导，重新记录。


*牙刷待机一段时间会自动返回主界面。




使用步骤

请按照以下步骤使用牙刷：


- ① 安装刷头




- ② 沾湿刷头




- ③ 在刷毛上挤少量牙膏




- ④ 合适角度(约 45 度)放入口中



- ⑤ 按开关开启牙刷



- ⑥ 180 度全面清洁牙齿






您的 planck O1 可安全用于：

- 牙齿矫正器 (在牙齿矫正器上使用时，牙刷头磨损较快)。
- 修复牙体 (补牙、齿冠、烤瓷牙)。

日常保养

- ① 卸下刷头并用温水冲洗金属轴。确保清除所有残留牙膏。

- ② 使用湿布擦拭牙刷手柄的整个表面。
- ③ 每次刷牙后冲洗牙刷头和刷毛。
- ④ 从牙刷柄上卸下牙刷头，每周至少用温水冲洗一次牙刷头连接处。
- ⑤ 使用湿布擦拭无线充电基座和电源适配器表面。确保清除表面所有的牙膏或其他残留物。



存放

如果长时间不使用 planck O1, 请为牙刷手柄充满电, 从电源插座中拔出电源适配器, 清洁每个部件并且存放在阴凉、干燥且远离阳光直射的地方。

规格参数

产品名称: planck O1 自适应声波电动牙刷

产品型号: planck O1

防水等级: IPX7

额定电压: 7.4V

额定功率: 4.0W

工作频率: 2.402-2.480GHz

发射功率(EIRP): $\leq 2\text{dBm}$

电池容量: $> 1040\text{mAh}$

适配器输入: 100-240V ~ 50-60Hz, $\leq 350\text{mA}$

制造商: 深圳市一唔未来科技有限公司

服务与支持

当您的牙刷出现问题的时候, 难免遇到没有时间或者不方便现场维护的情况, 请不用担心, **evowera** 寄修服务帮你实现足不出户的售后支持。

可以通过以下申请途径获取帮助:

evowera App 申请

- 进入App, 选择寄修服务, 点击我要寄修, 按照提示填写寄修申请。

- 已经提交申请的用户, 可以点击寄修查询, 查询寄修进度。

保修限制

国际保修条款里不包括以下各项：

- 刷头。
- 因使用未经授权的设备造成的损坏。
- 由于误用、滥用、疏忽、改装或擅自修理造成的损坏。
- 正常磨损, 包括裂口、擦痕、磨损、变色或褪色等。

内容如有更新, 恕不另行通知。

您可以在 **evowera** 官方网站查询最新版本

<http://www.evowera.com/plancko1>

免責聲明和安全注意事項

感謝您購買 **evowera®planck®O1**自動適應聲波電動牙刷。在使用本產品前，請仔細閱讀本說明書並妥善保管以備日後參考。本產品屬於私人用品，一旦使用，即被視為對本聲明全部內容的認可和接受。請嚴格遵守手冊、產品說明書和相關的法律法規、政策、準則安裝和使用該產品。在使用產品過程中，使用者承諾對自己的行為及因此而產生的所有後果負責。因用戶不當使用、安裝、改裝造成的任何損失，深圳市一唔未來科技有限公司將不承擔任何法律責任。

evowera 和 **planck** 是深圳市一唔未來科技有限公司的商標。本文出現的產品名稱、品牌等，均為其所屬公司的商標或註冊商標。本產品及手冊為深圳市一唔未來科技有限公司版權所有。未經許可，不得以任何形式複印翻印。

關於不同語言版本的免責聲明可能存在的語義差異，中國以中文版為準，其他國家或地區以英文版為準。

重要安全資訊


危險

- 使電源適配器遠離水源。請勿將它放置或存放在任何有水的容器的上方或附近。請勿將電源適配器侵入水或任何其他液體中。清潔後，確保電源適配器完全乾燥，再將其連接至電源。

警告

- 應始終使用原裝型號的電源適配器進行更換，以免發生危險。
- 切勿在戶外或高溫表面附近使用電源適配器。
- 如果本產品受到任何損壞（刷頭、牙刷手柄、無線充電基座或電源適配器），請停止使用。
- 不要讓兒童在無人監督的情況下對本產品進行使用、清潔和保養。
- 切勿讓兒童玩弄本產品。
- 請勿在洗碗機中清洗牙刷頭、牙刷手柄、無線充電基座和電源適配器。
- 如果您在兩個月內接受過口腔或牙齦手術，請在使用本產品前先諮詢您的牙醫。
- 如果在使用本產品後牙齦大量出血或在使用一周後仍會出血，請諮詢您的牙醫。如果在使用 **planck O1** 時感覺不適或疼痛，也請諮詢您的牙醫。
- **planck O1** 符合電磁裝置的安全標準。有關任何涉及心臟起搏器或其他植入裝置的問題，請在使用之前諮詢醫生或相關植入裝置的設備製造商。
- 如果您有醫學問題，請在使用 **planck O1** 前諮詢醫生。
- 本產品設計僅用於清潔牙齒、牙齦和舌頭。請勿將其用作任何其它用途。如果感覺任何不適或疼痛，請停止使用本產品並與醫生聯繫。
- **planck O1** 為私人用品，不可供牙醫診所或機構對多位患者使用。
- 請停止使用變形、刷毛彎曲或 **planck O1** 螢幕提示超出使用壽命的牙刷頭。請勿使用非製造商推薦的其他刷頭。

整體部件圖



① 牙刷手柄

② 刷頭軸

③ 功能按鍵 (模式/力度)

④ 電源按鍵

⑤ 顯示幕

⑥ 牙刷頭

⑦ 牙刷頭保護套

⑧ 無線充電基座

⑨ 充電底座 USB 接頭

⑩ 電源適配器

⑪ 適配器 USB 介面


⑫ 適配器電源插頭

⑬ 快速入門手冊

充電


首次使用可能電量不足，需要充電，充電需要注意以下事項：

①



正確將牙刷放置在無線充電基座上，切勿硬塞防止牙刷手柄表面磨損。

②



在交流电 100-240V, 50-60Hz 电源插座上充电。

安裝 evowera App

掃描下方二維碼或在應用商店搜索並下載安裝“evowera App”，安裝完畢後，請按照 App 指引註冊 evowera 帳戶並登錄。



二維碼

啟動 planck O1

為保證產品功能的完整體驗，享受正常便捷的售後服務，首次使用 planck O1 需連接手機並通過 evowera App 啟動。請按照以下步驟完成啟動操作：


喚醒牙刷

- 通過 **短按 1 次 功能按鍵 / 短按 1 次 電源按鍵 / 輕輕晃動牙刷** 三種方式可喚醒牙刷。


連接並啟動

- 打開已經註冊並完成登錄的 App，進入設備連接介面。將牙刷放置於靠近手機的位置，按照 App 指引連接牙刷並完成啟動。

啟動過程中請確保移動設備可正常接入互聯網。若啟動失敗，請退出重試。多次啟動失敗，請聯繫 **evowera**。



按鍵示意圖



連接設備示意圖

按鍵功能基礎操作

快速刷牙

短按 1 次 電源按鍵 開啟或關閉刷頭振動。

選擇以及更換刷牙模式

當牙刷刷頭處於靜止狀態且牙刷螢幕介面為主介面時：


- ① **短按 1 次 功能按鍵** 進入模式選擇介面，根據牙刷螢幕顯示內容，通過 **短按 功能按鍵** 進行模式選擇。
- ② **長按 功能按鍵** 確定模式選擇並返回主介面。或 **短按 1 次 電源按鍵** 確定模式選擇並開啟刷頭振動。

調整刷牙力度

注意：牙刷力度調節只能在牙刷刷頭振動的同時進行調節。

- 梯度式調節：**短按 1 次 功能按鍵** 升高一級刷牙力度（當到達最強安全力度時，繼續 **短按 1 次 功能按鍵** 力度降至最弱）

- 無級變速式：**長按 功能按鍵** 並保持不放，刷牙力度持續增強。**放開 功能按鍵**，牙刷將保持放開瞬間的力度。（當到達最強安全力度時，力度重新由最弱向上遞增）。



查看刷牙數據

刷頭振動時：

- ① **短按 1 次 電源按鍵** 關閉刷頭振動，牙刷螢幕出現“刷牙覆蓋率”介面。
- ② 繼續 **短按 1 次 功能按鍵** 牙刷螢幕進入“刷牙評分”介面。
- ③ 再次 **短按 1 次 功能按鍵** 返回主介面。

刷頭靜止時：


- ① 連續 **短按 2 次 功能按鍵** 查看上一次刷牙記錄。
- ② 繼續 **短按 1 次 功能按鍵** 返回主介面。

女性生理期記錄

當牙刷刷頭處於靜止狀態且牙刷螢幕介面為主介面時：

- ① **長按 3 秒 功能按鍵** 進入女性生理期記錄介面。
- ② 根據螢幕介面資訊提示，**長按 1 次 功能按鍵** 記錄女性生理期，並可閱讀到牙刷螢幕顯示的記錄成功資訊。
- ③ 如果記錄失敗，請根據螢幕介面資訊引導，重新記錄。


*牙刷待機一段時間會自動返回主介面。




使用步驟

請按照以下步驟使用牙刷：


- ① 安裝刷頭




- ② 沾濕刷頭




- ③ 在刷毛上擠少量牙膏




- ④ 合適角度(約 45 度)放入口中



- ⑤ 按開關鍵開啟振動



- ⑥ 180 度全面清潔牙齒






您的 planck O1 可安全用於：

- 牙齒矯正器 (在牙齒矯正器上使用時，牙刷頭磨損較快)。
- 修復牙體 (補牙、齒冠、烤瓷牙)。

日常保養

- ① 卸下刷頭並用溫水沖洗金屬軸。確保清除所有殘留牙膏。

- ② 使用濕布擦拭牙刷手柄的整個表面。
- ③ 每次刷牙後沖洗牙刷頭和刷毛。
- ④ 從牙刷柄上卸下牙刷頭，每週至少用溫水沖洗一次牙刷頭連接處。
- ⑤ 使用濕布擦拭無線充電基座和電源適配器表面。確保清除表面所有的牙膏或其他殘留物。



存放

如果長時間不使用 **planck O1**，請為牙刷手柄充滿電，從電源插座中拔出電源適配器，清潔每個部件並且存放在陰涼、乾燥且遠離陽光直射的地方。

规格参数

產品名稱：planck O1 自動適應聲波電動牙刷

產品型號：planck O1

防水等級：IPX7

額定電壓：7.4V

額定功率：4.0W

工作頻率：2.402-2.480GHz

發射功率(EIRP)：≤2dBm

電池容量：>1040mAh

適配器輸入：100-240V ~ 50-60Hz，≤350mA

製造商：深圳市一唔未来科技有限公司

服務與支援

當您的牙刷出現問題的時候，難免遇到沒有時間或者不方便現場維護的情況，請不用擔心，**evowera** 寄修服務幫你實現足不出戶的售後支持。

可以通過以下申請途徑獲取幫助：

evowera App 申請

- 進入 App，選擇寄修服務，點擊我要寄修，按照提示填寫寄修申請。

- 已經提交申請的用戶, 可以點擊寄修查詢, 查詢寄修進度。

保修限制

國際保修條款裡不包括以下各項：

- 刷頭。
- 因使用未授權的設備造成的損壞。
- 由於誤用、濫用、疏忽、改裝或擅自修理造成的損壞。
- 正常磨損, 包括裂口、擦痕、磨損、變色或褪色等。

內容如有更新, 恕不另行通知。

您可以在 **evowera** 官方網站查詢最新版本

<http://www.evowera.com/plancko1>

Compliance Information

FCC Compliance Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20 cm between the radiator& your body.

Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

EU Compliance Statement

Shenzhen EVOWERA Technology Co.,Ltd. hereby declares that this device is in compliance with the essential

requirements and other relevant provisions of the RED Directive.

A copy of the EU Declaration of Conformity is available online at www.evowera.com.

RoHS



